




Window extender is 14 gauge SS and should extend out 1.5 inches past the outer diameter of the chamber



Both the window extender and manway should not go into the tube

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		NAME	DATE	Barley Chamber		
		DIMENSIONS ARE IN INCHES TOLERANCES: FRACTIONAL ± ANGULAR: MACH ± BEND ± TWO PLACE DECIMAL ± THREE PLACE DECIMAL ±	DRAWN	TF	1/11/2011			
		INTERPRET GEOMETRIC TOLERANCING PER:	CHECKED			SIZE DWG. NO. REV		
		MATERIAL	ENG APPR.					
NEXT ASSY	USED ON	FINISH	MFG APPR.			COMMENTS: Top flange and support beam are not pictured in this drawing		
APPLICATION		DO NOT SCALE DRAWING	Q.A.					
			COMMENTS:					